LIFAN WIRING

IMPORTANT: PLEASE READ BEFORE WIRING UP THE ENGINE IGNITION:

Check that the thin black wire coming from under the tank (F terminal) is disconnected from the thin black wire which is coming from the small gold metal box (M terminal). Yellow wire from gold box should remain or be connected to the yellow wire coming from engine casing as stated in 'other' below. Then proceed by following the instructions below:

IGNITION BOX	TO	ENGINE
White wire in black sleeve/Ring Terminal	~ ~ ~ ~	Exposed nut on starter motor solenoid Also connect live wire from battery to here
Thin black wire/ring terminal (not always present)	~ ~ ~ ~	Ground between ignition box and engine
Black & White wire/F Spade Terminal	~ ~ ~ ~	M Spade Terminal on starter motor solenoid
Black wire/M Terminal	~ ~ ~ ~	Black wire in black sleeve/F Terminal from under tank
Brown wire/M Terminal	~ ~ ~ ~	Brown wire/F Terminal from charging coils into side of engine casing
Thin Black wire/F Terminal	~ ~ ~ ~	Thin black wire/M Terminal from small gold oil alert box
OTHER	**TO**	**ENGINE**
Yellow wire/F Terminal from small gold oil alert box	~ ~ ~ ~	Yellow wire/M Terminal from engine casing oil alert